

FITTING INSTRUCTIONS

Mégane convertible rear screen

Set the glass flat for a few hours (not required).



Mounting the new window: align the window zipper teeth (pink) with the first hood teeth (green) as shown in this picture, the silver teeth of the screen must be aligned with the very first teeth of the hood. The teeth of the end of the zipper of the new window are also silver, but these are the starting ones that are important.



Raise the front and then the back of the convertible top at 90° like this:



Gently close the clasp to the right, leave it on the zip fastener at the end. Hook the clip on the starting part:



Leverage with a small flat screwdriver to remove the clip without damaging the zip fastener:



Insert the convertible top fabric into the rubber ring outdoors with a thin blade or a flat screwdriver:



Separate the zipper with the screwdriver:



Peel off the screen by pulling it inwards:



Operation completed, enjoy a perfect visibility!

